

NAPCO RP1 & RP2 KEYPAD QUICKGUIDE



Napco RP1



Napco RP2

Arm System – All protected windows and doors must be closed. Ready light should be green.

- **Away**—Press Code then **ON/OFF** Key
Arms all devices including motion detectors.
- **Stay**— Press **INTERIOR** key. “Bypass” will appear in the top left corner of keypad. Press Code, Press **ON/OFF** key.
Arms all devices and automatically bypass all motion detectors.
- **Instant**—Press **INTERIOR** key, Press Code, Press **ON/OFF** Key, Press **INSTANT** key (Red armed light will flash rapidly)
Arms entry doors without delay and bypass all motion detectors.
- **Easy Arm Away**-Press **ON/OFF** key (If Programmed)
- **Easy Arm Stay**-Press **INTERIOR** Key, Press **ON/OFF** key (If Programmed)

Disarm System/Silence an Alarm: Enter code then **ENTER** key (After Silencing keypad will display zones activated.)

Reset System (Use after silencing and noting activated zones): Press **RESET** key

Chime On/Off: Press **MENU** button until “Activate/Deactive Chime” appears. Press **INTERIOR/YES** key

Bypass A Zone: Press **BYPASS** key. Then press two digit zone number to bypass. (ex: 4=04)
If successful “Bypass” will appear in top left hand corner of keypad.


Panic Buttons: Press and hold the following combination for 3 seconds

POLICE	FIRE DEPT.	AMBULANCE/EMS
9P & *	7F & *	8A & *

Change or Add Additional Codes: Enter Code then Press **FUNCTION** Key until “Activate Program”. Press **INTERIOR/YES** key. Enter Digits of User code to be programmed (ex: 4=04) (more than 1 code in system). Press **FUNCTION** key twice. Enter new user code (up to 6 digits). Press **ON/OFF** to save code.

IF MONITORED CUSTOMER: Send code change to codechange@ialarmnj.com. We can connect and handle code changes for you.

Delete A User Code: Enter Code then Press **FUNCTION** Key until “Activate Program”. Press **INTERIOR/YES** key. Enter digits of code user number (ex: 4=04) to be programmed. Press

FUNCTION key twice. Press , 0 to erase each digit of the user code. Press **ON/OFF** key at end to save changes.

Sending a Test Signal: Press **FUNCTION** key until display reads “Activate Dialer Test”. Press **INTERIOR/YES** key.