


# 2GIG GC3 QUICKGUIDE



2GIG GC3 Keypad



System Icons



Bypass Screen



Panic Buttons

**Arm System** – All protected windows and doors must be closed. Ready light should be green.

- **Away**— From Home Screen- Press **AWAY** button Arms all devices including motion detectors.
- **Stay**— From Home Screen- Press **STAY** button Arms all devices and automatically bypass all motion detectors.
- **Instant**— From Home Screen: Uncheck **ENTRY DELAY**, Press **STAY** Arms entry doors without delay and bypass all motion detectors.
- **Maximum**: From Home Screen: Uncheck **ENTRY DELAY**, Press **AWAY** Arms all devices and will arm all entry doors without an entry delay.

**Disarm System:** From the **System Armed** page, Press **DISARM**, Enter Code.

**Silence an Alarm:** From the **System Armed** page, Press **DISARM**, Enter Code.

**Silence/Acknowledge Trouble Beeps:** Tap the screen to illuminate. Tap the blinking **Message Bubble** – top of screen. Tap **Alerts**. **Trouble Condition** will be displayed. Press the **Back arrow**. **Trouble Condition** has been **Silenced/Acknowledged**.

**Reset System/Clear Alarm History:** Tap the **Message** system icon. Review the **Alarms** list then tap **Clear Alarm History**.

**Door Chime On/Off:** At the **Home** screen, tap **System Settings**. Enter your four digit **Master Code**. At the **System Settings** menu, tap **Sounds**. Swipe down to select **Voice and Chime**. Turn on or off and adjust volume.

**Bypass Zone(s):** (Two Methods Available)

**Forced Bypass:** Below the **Sensors Not Ready** list, tap **BYPASS ALL**. Enter User Code. When system status message changes to **System Ready to Arm (BYPASS)** you can arm the system.

**Manually Bypass:** At the **Home** screen, tap **System Settings**. Enter **User Code**. Tap **Bypass Sensors**. On the desired slide control, swipe right to add the sensor to the systems list of **Bypassed Sensors**.

**Panic Buttons:** Press **Alarm (+)** button on the front of Alarm Keypad. Select **PANIC**, **FIRE** or **EMERGENCY (EMS)**. Press and HOLD selection for 2 or more seconds.

**Change or Add Additional Codes:** At the **Home** screen, tap **System Settings**. Enter **Master User Code**. Tap **Users**. Tap **Add User**. Enter a name for the **New User**, tap **Next**. Enter a unique **four-digit code** for the **New User**. Tap **Next**. Re-enter the **four digit code** for the **New User** to confirm. Tap **Next**.

**Delete A User Code:** At the **Home** screen, tap **System Settings**. Enter **Master User Code**. Tap **Users**. Tap the **Garbage Can** icon next to the desired user you wish to delete. Tap **Delete**.

**Sending a Test Signal:** At the **Home** screen, tap **System Settings**. Enter **Master User Code**. Tap **System Tests**. Tap **Sensors Test**. Walk to and trigger each sensor on the list.

**Door/Window contacts**, open and close the door or window.

**Motion Detectors**, wait five minutes then walk through the protected area.

**Panic Buttons, Key Fobs, and Wireless Key Fobs**, press a key or button on the device.

**Smoke/Heat/Freeze Alarms, Carbon Monoxide Detectors, or Glass Break Detectors**, press the products **Test** button. **Green Bar** indicates successful test, **Red Bar** indicates failed test.